

# CUPID'S ARROW




## Overview

Ying Lin

Jet Propulsion Laboratory


August 18, 2018




# CUPID'S ARROW

Why is Venus so different than Earth?

- Address Planetary Decadal Survey Goals, specifically Objective IA: 'How did the atmosphere of Venus form and evolve'
- Measure the concentrations of noble gases and isotope ratios in Venus atmosphere @110 km (below the homopause) to provide key information on the formation and evolution of Venus.
- Noble Gases are tracers of planetary evolution
  - the supply of volatiles from the solar nebula
  - the supply of volatiles by asteroids and comets
  - the escape rate of planetary atmospheres
  - the degassing of the interior (volcanism)
  - the timing of these events





# Noble gases are tracers of planetary evolution



# CUPID'S ARROW

## Baseline Mission

- Flight time ~430 days
- Launch in 2022, December
- Launch C3 < 9 km<sup>2</sup>/s<sup>2</sup>
- Arrival Vinf. = ~2.7 km/s
- Initial large elliptical orbit ~20 days



- Spin Stabilized for cruise and atmospheric pass
- Separate solid for VOI
- DV Monoprop capability ~60 m/s (in probe)
- DV VOI Capability ~433 m/s




# CUPID'S ARROW

## Atmospheric Entry Conditions



Entry velocity of 10 km/s  
Target altitude of 110 km

Homopause is between  
119 km (evening  
terminator) and 135 km  
(night side close to the  
morning terminator)  
with a weak  
dependence on latitude  
(Limaye et al., 2017)



# CUPID'S ARROW

## Mechanical Configuration



Predecisional: For Discussion Purposes Only

[jpl.nasa.gov](http://jpl.nasa.gov)

# JPL Mini Quadra-pole Ion Trap Mass Spec (QITMS)



- No discrete wires to make electrical connections to mass spectrometer parts.
- 4 kg mass; 2U volume
- Extremely robust against shock/vibe loads
- Very stable measurements



- Each generation of QITMS is getting progressively smaller with lower mass and without compromising performance
  - 8kg  $\rightarrow$  4kg
- Builds on previous developments for HEOMD; e-Nose and VCAM.


QITMS Isotopic Precision is 3-5 times better than required

# CUPID'S ARROW

---

## Summary

- This concept offers a new and game changing approach for atmospheric sampling at Venus
- Understanding how Earth and Venus have diverged in their geological history is a key to understanding the habitability of earth-like planets.
- A miniaturized QITMS measuring the concentrations of noble gases and isotope ratios in Venus atmosphere would provide key information on the formation and evolution of Venus.
- A free-flying SmallSat probe may be able to deliver high-priority science at Venus for a fraction of the cost of a conventional Discovery mission.





**Jet Propulsion Laboratory**  
California Institute of Technology

---

[jpl.nasa.gov](http://jpl.nasa.gov)