

# CubeSat hyperspectral imaging technology

Goddard Planetary CubeSat symposium

June 27<sup>th</sup>, 2019

*Chris Mann, Nanohmics, Inc.* | [cmann@nanohmics.com](mailto:cmann@nanohmics.com)

**Nanohmics:** Dan Mitchell, Giri Joshi, Kieran Lerch, Leslie Wood, Kyle Hoover, Jon Diaz, Noel Arguello, Jesus Meza-Galvan, Josh Reudin, Alex Greis, Byron Zollars

**University of Maryland:** Tilak Hewagama, Lori Feaga, Jessica Sunshine



# Overview

We are fabricating a micro-optical chip to augment focal planes, converting standard image sensors into hyperspectral cameras for CubeSats



# Nanohmics Background

- Based in Austin, TX
- Founded 2002
- Staff of ~40
  - Primarily scientists, engineers, and technicians
- 13,500 sq. ft. of industrial R&D flex space
- Member of the NNCI at University of Texas at Austin
- Core capabilities:
  - Microfabrication
  - Novel materials
  - Electro-optics
  - Instrumentation engineering
  - Sensors & diagnostics




# Program Background

- NASA STTR Phase II R&D program with University of Maryland to develop CubeSat hyperspectral imaging sensors
  - Demonstrate in VIS, move into IR in Phase II-E/III
- We are developing a ~1 gram chip that converts a camera into a hyperspectral camera *with full spatial-spectral-temporal registration*
  - Does not require scanning in any dimension (spatial, spectral, or temporal)
  - No spectral filters, radiometrically efficient
  - Trades spatial for spectral information
  - Prototype delivery in September



# Hyperspectral chip

- Focal plane augmentation, add ~1 gram of mass by adding a chip very nearly on an FPA
  - Shifts focal plane by  $\leq 1$  mm
- A prototype chip is shown on right
  - 100 x 100 spatial elements
  - Target for Gen 1 prototype:
    - 450-950nm bandwidth
    - 5-10nm spectral resolution
  - Frame rate limited by radiometry, underlying image sensor
- Secret sauce:
  - Computational spectroscopy...



# “Diagonal” spectroscopy

- Traditional spectroscopy separates bands in essentially linear ways



$$S(\lambda) = a_1 I_1 + \dots + a_N I_N = \begin{pmatrix} a_1 & 0 & 0 & 0 \\ 0 & a_2 & 0 & 0 \\ 0 & 0 & \dots & 0 \\ 0 & 0 & 0 & a_N \end{pmatrix} \begin{pmatrix} I_1 \\ I_1 \\ \dots \\ I_N \end{pmatrix} = \mathbf{A}\mathbf{I}$$

# “Non-diagonal” spectroscopy



- Non-diagonal spectroscopy separates bands in complicated ways, with multiple spectral lines on each detector (e.g., FTIR)



$$S(\lambda) = \begin{pmatrix} a_{11} & a_{12} & \dots & a_{1N} \\ a_{21} & a_{22} & \dots & a_{2N} \\ \dots & \dots & \dots & \dots \\ a_{M1} & a_{M2} & \dots & a_{MN} \end{pmatrix} \begin{pmatrix} I_1 \\ I_2 \\ \dots \\ I_N \end{pmatrix} = AI$$

# Mie scattering for spectral dispersion

$ka = 1.0$     $ka = 1.1$     $ka = 1.5$




$$k = \frac{2\pi}{\lambda}$$

$a$  = radius of scatterer

# Single element in the hyperspectral array


- Concentrator improves radiative throughput, homogenizes input light
- Aperture provides spatial filter, sets up a reproducible light source (*ala* entry slit to monochromator)
- Dispersive media separates light
- Isolators prevent crosstalk
- Detector array detects a wavelength and polarization-dependent speckle pattern




**Wavelength-dependent speckle pattern reveals spectral content**



# Optical concentration




Optical micrograph – view from top





Cleaved sample, cross-section  
(note, different sample)


# Tailoring concentrator entrance




- Perform a post-etch sidewall cleanup to maximize fill factor, reduce roughness
- Tunable chemical & plasma etch processes





# Speckling media



Integrate scattering media with  
photolithographic processes




# Scene element isolation




# Wavelength-dependent speckle


- Each speckle pattern evolves differently




500nm




565nm




630nm




700nm



# Computational reconstruction



$$S(\lambda) = a_1 I_1 + \dots + a_N I_N = \begin{pmatrix} a_1 & 0 & 0 & 0 \\ 0 & a_2 & 0 & 0 \\ 0 & 0 & \dots & 0 \\ 0 & 0 & 0 & a_N \end{pmatrix} \begin{pmatrix} I_1 \\ I_2 \\ \dots \\ I_N \end{pmatrix} = AI$$




$$S(\lambda) = \begin{pmatrix} a_{11} & a_{12} & \dots & a_{1N} \\ a_{21} & a_{22} & \dots & a_{2N} \\ \dots & \dots & \dots & \dots \\ a_{M1} & a_{M2} & \dots & a_{MN} \end{pmatrix} \begin{pmatrix} I_1 \\ I_2 \\ \dots \\ I_N \end{pmatrix} = AI$$

- Spectrum is determined by coefficients,  $x$ :
  - $Min(\|Tx - S\| + \alpha\|Dx\| + \beta\|x\|)$
  - $T$  the calibrated transfer matrix
  - $S$  the measured speckle pattern vector
  - $D$  the difference operator
  - $\alpha, \beta$  are reconstruction stabilization parameters and are chosen to be as small as possible
- Calculate after downlink, not on-board (excepting potential preview images)

# CubeSat telescopes

- Sensor puts few constraints on telescope
  - $f/4$  or slower is best, though concentrators can be tailored for faster optics
  - Faster/wider FOV optics, prefer image-space telecentric
- 1U telescope options:
  - 80mm Cassegrain (right) for long-range
  - Central obscuration blocks ballistic rays
- Because of our large spatial elements ( $\sim 90\mu\text{m}$ ), relaxed imaging constraints
  - Deployable optics may be an option



# Niche for technology


- Applications where pushbroom is inappropriate
  - Pushbroom provides better spectral, spatial resolution
- Great for transient, full-frame operation
  - CubeSats without pointing control
  - Auxiliary instrument that doesn't constrain platform motion
  - Semi-disposable CubeSats
    - Comet approach, high probability of damage
    - Surface approach & impactors
- Applications with modest spectral, spatial tradeoffs
  - Color filter wheels take up space and mass, have moving parts prone to failure




# Questions?



# Calibration – Spectral Engine



# Custom spectra



**DMDdriver**

DMD Line Control

Line Column 960

Line Width 5  Invert BY

Spectrometer Control

Close Spectrometer

Int. Time (usec) 15000

Sample Averaging

Peak wavelength (nm) **523.995**

Amplitude 3885

Spectrometer Status

Reading OK.

Capture Settings

Base spectrum file name: spec

Test Notes

Batch Control

DMD Column Begin 400

DMD Column End 1500




DMD Column Inc 1

Batch Status

Stopped





Intensity 1080

name: spec



# Reconstruction stability

Under  
constrained



Over  
constrained

